

LoveThisBagDryer!™

Reduce plastic pollution and save money.

Included: Wood base; 2 short dowels; 4 long dowels; packet w/ EZ Anchor, one 1" chrome plated screw, one 1" black screw, & one 1½" black screw.

Need: Toothpick, Elmer's or wood glue, hammer, 2 clean rags, mineral oil (*not* olive, nut, or vegetable oil which go rancid), measuring tape or ruler, small nail, medium size Phillips screwdriver.

Glue for strength: Drip a little Elmer's or wood glue into each hole in the base. With a toothpick, spread glue up the holes' edges. Twist or lightly hammer-tap dowels into holes so *red* ends reach the bottoms. Adjust the dowels' angles so they line up. Let dry at least 1 hour.

Oil to protect from dirt and water damage: After glue has set, with a clean dry rag gently wipe oil on the dowels and on the face & edges of the base--*not* on back of base (so cork bumpers stick). Re-apply oil every 15 minutes until it stays on the wood surface; wipe it off with another clean dry rag. Let dry overnight.

For counter: Place on base. Ready!

To mount vertically: See enclosed cards for how to mount to wood, drywall, or into a stud.

[To mount to masonry or metal, use hardware made for those materials.]