

LoveThisNapkinRack!™

Reduce pollution, save \$

Included: Wood base with masking tape covering black-board strip; four small dowels; chalk stick; packet with EZ Anchor, one 1" chrome plated screw, one 1" black screw, & one 1½" black screw.

Need: Toothpick; Elmer's or wood glue; hammer; two clean rags; mineral oil (*not* vegetable, olive, or nut oil which go rancid); small nail; measuring tape or ruler; medium size Phillips screwdriver.

Glue for strength: Drip a little glue into each hole in the base. With a toothpick, spread glue up the holes' edges. Twist or lightly hammer-tap dowels into holes so *red* ends reach the bottoms. Let dry at least 1 hour.

Oil to protect from dirt & water damage: Firmly press masking tape to blackboard strip. With a clean dry rag, gently wipe oil on the dowels and on face & edges of base. Keep oil *off* black-board strip (protected by masking tape) and *off* back of base (so cork bumpers stick). Re-apply oil every 15 minutes until it remains on the wood surface; wipe it off with another clean dry rag. Let dry overnight. Remove tape.

To mount vertically: See enclosed cards for how to mount to wood, drywall, or into a stud.

[To mount to masonry or metal, use hardware made for those materials.]